



Hurripanel™

Storm Panel Measurement Aid

This form can be filled out here or printed.

If filling out on your computer, please save this form to your hard drive with a new name. Then attach the completed form to an e-mail to hurripanel@comcast.net when you are ready for your estimate.

If filled out by hand, call [1.281.488.3900](tel:1.281.488.3900) or [1.877.424.7616](tel:1.877.424.7616) when you are ready for your estimate.

Please call us or e-mail us with any questions.

Name: _____

Address, City, State, Zip: _____

Phone No.: _____ e-mail address: _____

Measuring Guidelines

A form is supplied on the following page to aid your calculations. In all cases, describe any obstructions or special circumstances and we will help you determine the best solution. Photos are very helpful.

NOTE: Round all dimensions up to the nearest whole inch.

Wood-framed buildings (including stucco- and brick-faced buildings)

Measure your openings and note on form on next page. Storm panels should be fastened to studs. Using a stud finder, determine the center-to-center distance of the studs on either side of the opening. Homes have studs on each side of the windows and doors. Windows and doors have headers above which you can install anchors to attach the panels. Anchors should be no closer than 2" to the edge of the panel. Therefore, add a minimum of 4" to the vertical and horizontal dimension to accommodate the anchors - except when the opening is a door or a window that goes all the way to the ground. In that case, you only need to add an extra 2" for anchors at the top. (You may add more to each dimension, especially if you wish to completely cover the trim of your doors and windows.) This will give the "panel width" and "panel height" shown on the form.

Concrete block/cinder block framed buildings (including stucco- and brick-faced buildings)

Measure your opening and note on form on next page. Anchors should be no closer than 2" to the edge of the panel. Therefore, add a minimum of 4" to the vertical and horizontal dimension to accommodate the anchors, except when the opening is a door or a window that goes all the way to the ground. In that case, you only need to add an extra 2" for anchors at the top. (You may add more to each dimension, especially if you wish to completely cover wide trim on your doors and windows.) This will give the "panel width" and "panel height" shown on the form.

Large Openings

Patio doors and other openings that are 4 feet or wider will require the use of aluminum H connectors or similar products. See our accessories section for details. We can also include these in your quote if you wish. Figure in an overlap of 6" for these sections.

Fasteners/Anchors

Anchors should be installed a maximum of 3" from each end and then 12" on center, unless your distance from the coast requires a more stringent approach of 2" from each end and then 6" on center (designated by your state requirements).

hurripanel@comcast.net

Panel Type & Color

GE Lexan - clear

Inteplast Polypropylene - opaque white

Polycarbonate - clear

Polycarbonate - bronze

Polycarbonate - ice

Cutting

Pre-Cut

I Will Cut To Size

Accessories

Include price of any required H-channels, etc. in quote

Shipping

Ship to Me

I Will Pick-up

Measuring

Opening	Description (window, patio door, etc.)	Opening Height	Opening Width	Panel Height	Panel Width	Obstructions
1						
2						
3						
4						
5						
6						
7						
8						
9						
10						
11						
12						
13						
14						
15						
16						
17						
18						
19						
20						